

# Acrylic Accessory Panel 60



No Tools  
Required

# vari®

**1**

x1

x2

x2

x1

x1

x1

x10

Position each clamp at about the same distance between the corner of the desk and the cable management tray. Slide the clamps onto the desk and tighten using the hand bolts.

**2**

Carefully slide the acrylic panel all the way down into the brackets. The levered brackets are designed to hold the panel securely in place. As you gently push the panel down, the levers will move to accommodate the panel.

**3**

Each accessory - marker board, cork board, tray, and pencil holder - will need to have pegs attached to it. For the white board and cork board, slide the flat back of the peg into the opening along the edge. For the tray and pencil holder, push the pointed front of the peg through the opening.

**4**

To attach the accessories to the panel, line the pegs up with the peg holes and push them into place.

(800) 207-2587