


# VariDesk® Portable Laptop Stand




**vari**®

1





**CAUTION:**  
Pinch point. Risk of finger injury.  
Use caution when pulling handle.





Squeeze the handle towards the upper grip to unlock the legs and platform; pull the legs apart. Release the handle to lock the unit in place.

2



Place the VariDesk® Portable Laptop Stand on a flat, level surface away from the surface edge. Confirm that the legs are locked and the unit is stable before placing a laptop or similar device on the platform.

3



To close, squeeze the handle until the locking mechanism allows the platform and legs to release. Tilt the platform down toward the front leg, then pull the back leg towards the bottom of the plate surface. Release the handle to lock in place in the stored position.



**WARNING:** Pinch point. Risk of finger injury. Use caution when raising and lowering.



**WARNING:** To prevent injuries or product failure, do not use the VariDesk Portable Laptop Stand for standing, climbing, or leaning. Do not use if laptop riser is damaged.



**(800) 207-2587**

Patent and trademark information: [vari.com/patents](https://vari.com/patents)  
©2020, 2021 Varidesk, LLC All rights reserved.