

Standing Work Station 36x24



2 People Recommended




Static Weight Capacity
250 lb (113.4 kg)



Functional Weight Capacity
10 lb (4.5 kg)


vari®

The functional weight limit refers to the weight a desktop or tabletop can support when height-adjusting, while the static weight limit means how much weight it can support while stationary.




x1

1



Slide the cable management tray into the notches above the bracket at the back of the desk, and push until it clicks into place.


2




Pull legs into upright position. Do not remove wingnuts from legs until the end of assembly.



x2




x1



x1




x2




x8

3



To lock the legs in place, insert a longer bolt in each hole at the bottom of each leg and tighten. We recommend having one person stabilize the legs while another secures the bolts.

4




Remove feet from the smaller included box. The feet are marked Front and Back. With the work station face side down, line up each foot with the corresponding Front and Back markers on the desktop corners.




(800) 207-2587

5




Insert shorter bolts into holes and tighten. Repeat on the left side.

6




With one person on each side of the desk, flip it into an upright position.

7



Unscrew the wingnuts in each leg to unlock the spring-assisted height-adjustment mechanism. You can dispose of wingnuts after removal.

8



Using the handles on each side of the work station, squeeze and pull up to lift to your preferred height. Squeeze and push down to lower.



WARNING: To prevent injuries and product failure, do not use the desk for climbing or leaning. Do not use if the product is damaged.