

Task Chair



2 People
Recommended





No Tools
Required




Holds up to
300 lb (136 kg)

vari®



Remove chair, air piston, foot ring, and base from the packaging. With the large end down, insert the piston through the foot ring (holes facing down) and into the base. With the piston firmly in place, slide the foot ring to the desired position, and turn the attached knob to the right to secure in place.





If the piston has a protective cap on the top, remove it before proceeding. Line up the hole underneath the seat with the top of the piston and base assembly. With another person's assistance, carefully lower the chair back onto the piston. Using even pressure, press down firmly on the seat cushion a few times to ensure the seat is fully engaged with the piston.

Once assembled, do not attempt to disassemble the chair, as doing so could damage the product.





WARNING: To prevent injuries and product failure, do not use this chair for standing, climbing, or leaning. Do not use if the chair is damaged or incorrectly assembled.



Adjustment Settings






To angle the arms or slide arms from front to back, push arms accordingly.




To adjust how easily the backrest reclines, turn the the knob on the right side forward to increase the tension and backwards to decrease the tension.





To adjust seat height, use the lever under the right side of the chair seat.



To adjust arm height, use the button under the armrest and pull up or push down.



To allow the backrest to recline, turn the knob on the left side to the unlocked position. To prevent the backrest from reclining, turn the knob to the locked position.



To adjust position of cushioned seat, use the lever on the left and pull the seat forward or push it back.

 (800) 207-2587