

Vari Tempur-Pedic Upholstered Chair

vari[®]




2 People
Recommended




Holds up to
275 lb (124.74 kg)



Components




x1
CHAIR



x1
CHAIR BASE



x1
BASE COVER




x5
CASTERS




x1
PISTON

1



Insert the five **CASTERS** into the **CHAIR BASE** until they snap into place. Once attached, flip the base over.


2



NOTE: Remove the **PROTECTIVE CAP** from the smaller end of the **PISTON**. Once the chair is assembled, the cap is no longer needed and can be discarded.


Slide the **BASE COVER** onto the **CHAIR BASE**, then insert the **PISTON** into the opening of the **CHAIR BASE**.

3




With assistance, carefully lower the **CHAIR SEAT** onto the **PISTON**. Apply firm, even pressure to the seat a few times to ensure the connection is fully secured.

Adjustment Options




SEAT HEIGHT ADJUSTMENT

While seated, pull the lever on the right side of the seat up, then hold it while raising or lowering the seat to adjust the seat height. When the lever is released, the seat height is locked. The seat height adjustment range is approximately 4.5".



CHAIR BACK TILT ADJUSTMENT

While seated, pull the lever on the right side of the seat out to unlock the tilt function. Lean back to recline the chair. To return to the upright position, sit upright and push the lever inward to lock the backrest. The range of motion is approximately 12°.



CHAIR TILT TENSION

Rotate the knob located underneath the seat clockwise for firmer resistance or counterclockwise for lighter resistance to adjust the amount of effort required to recline.



WARNING: To prevent injuries and product failure, do not use this chair for standing, climbing, or leaning. Do not use if the chair is damaged or incorrectly assembled.



(800) 207-2587

vari[®]