

Sit-Stand School Desk 3-12



Functional
Weight Capacity*
10 lb (4.5 kg)




Static
Weight Capacity
250 lb (113.4 kg)




2 People
Recommended

vari®




1




Pull the legs into the upright position. Do not remove the wingnuts from the legs until the end of assembly.


2



To lock the legs in place, insert a longer bolt in each hole at the bottom of each leg and tighten. We recommend having one person stabilize the legs while another secures the bolts.




3



Remove the feet from the smaller included box. Feet are marked Front and Back. With the desk face side down, line up each foot with corresponding Front and Back markers on the desktop corners.

4




Insert the shorter bolts into the holes and tighten. Repeat on the left side.




(800) 207-2587

5




With one person on each side of the desk, flip it into an upright position.

6



Unscrew the wingnuts in each leg to unlock the spring-assisted height-adjustment mechanism. You can dispose of the wingnuts after removal.

7



Squeeze the handles on each side of desk and pull up to lift the desk to your preferred height. Squeeze the handles again and push the desk down to lower.



WARNING: To prevent injuries and product failure, do not use the desk for climbing or leaning. Do not use if the product is damaged.